

PRDE20220405

## BLOCK AND GRAVEL FILTER






## FILTER FABRIC FENCE



### STRAW BALE BARRIER





## STORM DRAIN BARRIERS

<i>DRAWN BY</i> LINDA LANSING	CHECKED BY LINDA LIAN	APPROVED BY REVISED B COLLEEN HARRIS XXXX		Y	CITY STANDARD
FILE NAME F:\DWG\COMMON\STDS\CITY\2009\02_SD\02.03.05		DATE APPROVED 09/01/1992	DATE REVISED 06/01/2003	SCALE NTS	02.03.05

#### PRDE20220405

#### CONDITIONS WHERE PRACTICE APPLIES

- City of Puyallup
  Development & Permitting Services
  ISSUED PERMIT
  Building Planning
  Engineering Public Works
  Fire Traffic
- 1. BLOCK AND GRAVEL FILTER APPLICABLE FOR AREAS GREATER THAN 5% SLOPE.
- 2. FILTER FABRIC FENCE APPLICABLE WHERE THE INLET DRAINS A RELATIVELY SMALL (ONE ACRE OR LESS) AND FLAT AREA (LESS THAN 5% SLOPE).
- 3. STRAW BALE BARRIER APPLICABLE WHERE INLET DRAINS A RELATIVELY FLAT DISTURBED AREA ( LESS THAN 5% SLOPE) IN WHICH SHEET FLOW (NOT EXCEEDING 0.5 FT/SEC.) OCCURES. BARRIERS OF THIS TYPE SHOULD NOT BE PLACED AROUND INLETS RECEIVING CONCENTRATED FLOWS SUCH AS THOSE ALONG MAJOR STREETS AND HIGHWAYS.

#### 1. BLOCK AND GRAVEL FILTER - INSTALLATION PROCEDURE

- A: PLACE WIRE MESH OVER THE DROP INLET SO THAT THE WIRE EXTENDS A MINIMUM OF ONE FOOT BEYOND EACH SIDE OF THE INLET STRUCTURE. USE WIRE SCREEN WITH 1/2-INCH OPENINGS. IF MORE THAN ONE STRIP OF MESH IS NECESSARY, OVERLAP THE STRIPS. PLACE FILTER FABRIC\* OVER WIRE MESH.
- B: PLACE CONCRETE BLOCKS LENGTHWISE ON THEIR SIDES IN A SINGLE ROW AROUND THE PERIMETER OF THE INLET, SO THAT THE OPEN ENDS FACE OUTWARD, NOT UPWARD. THE ENDS OF ADJACENT BLOCKS SHOULD ABUT. THE HIEGHT OF THE BARRIER CAN BE VARIED, DEPENDING ON DESIGN NEEDS, BY STACKING COMBINATIONS OF BLOCKS THAT ARE 4-INCH, 8-INCH AND 12-INCH WIDE. THE ROW OF BLOCKS SHOULD BE AT LEAST 12-INCHES BUT NO GREATER THAN 24-INCHES HIGH.
- C: PLACE WIRE SCREEN OVER THE OVERSIDE VERTICAL FACE (OPEN END) OF THE CONCRETE BLOCKS TO PREVENT STONES FROM BEING WASHED THROUGH THE BLOCKS. USE WIRE SCREEN WITH 1/2-INCH OPENINGS.
- D: PILE STONES AGAINST THE WIRE MESH TO THE TOP OF THE BLOCKS. USE 3/4" MINUS WASHED GRAVEL.

#### 2. FILTER FABRIC FENCE - INSTALLATION PROCEDURE

- A: PLACE 2—INCH BY 2—INCH WOODEN STAKES AROUND THE PERIMETER OF THE INLET A MAXIMUM OF 3 FEET APART AND DRIVE THEM AT LEAST 8—INCHES INTO THE GROUND. THE STAKES MUST BE AT LEAST 3 FEET LONG.
- B: EXCAVATE A TRENCH APPROXIMATELY 8-INCHES WIDE AND 12-INCHES DEEP AROUND THE OUTSIDE PERIMETER OF THE STAKES.
- C: STAPLE THE FILTER FABRIC\* TO THE WOODEN STAKES SO THAT 32-INCHES OF THE FABRIC EXTENDS AND CAN BE FORMED INTO THE TRENCH, AND USE HEAVY-DUTY WIRE STAPLES AT LEAST 1/2-INCHES LONG.
- D: BACKFILL THE TRENCH WITH 3/4-INCH MINUS WASHED GRAVEL ALL THE WAY AROUND.

### 3. STRAW BALE BARRIER - INSTALLATION PROCEDURE

- A: EXCAVATE A 4-INCH DEEP TRENCH AROUND THE INLET. MAKE THE TRENCH AS WIDE AS A STRAW BALE.
- B: ORIENT STRAW BALES WITH THE BINDINGS AROUND THE SIDES OF THE BALES RATHER THAN OVER AND UNDER THE BALES.
- C: PLACE BALES LENGTHWISE AROUND THE INLET AND PRESS THE ENDS OF ADJACENT BALES SECURELY IN PLACE.
- D: DRIVE TWO 2-INCH BY 2-INCH STAKES THROUGH EACH BALE TO ANCHOR THE BALE SECURELY IN PLACE.
- E: BACKFILL THE EXCAVATED SOIL AND COMPACT IT AGAINST THE BALE.
- F: WEDGE LOOSE STRAW BETWEEN BALES TO PREVENT WATER FROM FLOWING BETWEEN BALES.

\* MIRAFI 140-N OR EQUIVALENT



# STORM DRAIN BARRIERS NOTES

CHECKED BY APPROVED BY
LINDA LIAN COLLEEN HAR

APPROVED BY
COLLEEN HARRIS

REVISED BY
XXXX

SCALE NTS 02.03.06