

OPERATIONS & MAINTENANCE MANUAL

2401 Inter

Parcel No. 2105200150


8/8/2025

Project Address

**2401 Inter Ave SE
Puyallup, WA 98372**

Owner

**MIKE PHAIR
615 EAST PIONEER #209
PUYALLUP, WA 98372**



Prepared By:

**David Hopkins
McInnis Engineering
535 Dock St. STE 111
Tacoma WA, 98402
(253) 414-1992**

Table of Contents

1.0	Maintenance and Source Control Manual Section 1 – Project Description.....	3
2.0	Maintenance and Source Control Manual Section 2 – Maintenance Importance and Intent	4
3.0	Maintenance and Source Control Manual Section 3 – Responsible Parties	5
4.0	Maintenance and Source Control Manual Section 4 – Facilities Requiring Maintenance	5
5.0	Maintenance and Source Control Manual Section 5 – Maintenance Instructions	5
6.0	Maintenance and Source Control Manual Section 6 – Vegetation Maintenance	5
7.0	Maintenance and Source Control Manual Section 7 – Pollution Source Control Measures	5
8.0	Maintenance and Source Control Manual Section 8 – Annual Cost of Maintenance.....	5

List of Figures

Figure 1: Map of Project Area.....	6
------------------------------------	---

List of Appendices

Appendix A – Maintenance Checklists	7
---	---

The proposed project is located 2401 Inter Ave SE

Puyallup, WA **98372**. Parcel Number is 2105200150. The parcel is located within Pierce County. The lot is 1.85 acres, 80,436 square feet (SF). The site is mainly gravel with shrubs and moderately tall grass. The site is zoned ML - Limited Manufacturing.

The project includes the proposed parking for trucks, with another parking area for employees of the neighboring Western parcel. Contech water quality chamber, ADS detention chamber and landscaped areas. Areas cleared or regraded not proposed for impervious surface shall be restored to meet the soil amendment BMP requirements per the 2021 Pierce County Stormwater Management and Site Development Manual Volume III, Section 3.1 and establish a dense cover of lawn, landscape, or groundcover. The plan proposes a total hard surface area of 63,475 SF. The proposed landscape is approximately 16,963 SF.

Water Quality

The project proposes more than 5,000 square feet of new or replaced hard surfaces and is required to apply water quality control. Water quality will be achieved by means of a Contech water quality system.

Flow Control

The project will utilize the StormChamber model 3500 and the outflow will be attenuated with a control manhole with orifices as shown on the project plan. The details for the StormChamber 3500 are also shown on the plans, and the WWHM calculations for the sizing of the StormChamber system is included as an appendix in this report.

Conveyance System

The roof runoff will be collected via PVC storm drainage piping and conveyed directly to the Stormtech Storm Chamber. All proposed pipes are required to be 12" diameter and minimum 0.5% slope. Per the Washington State Department of Ecology Western Washington Hydrology Model Version 2012 (WWHM).

Downstream Analysis

All stormwater will be directed to the swale at the northern end of the property that flows from east to west into a control structure. Though it is not on the Puyallup GIS yet, the water likely flows from the control structure to East Main and ultimately discharges into the Puyallup river. It is anticipated that no adverse impacts will result from the proposed project.

2.0 Maintenance and Source Control Manual Section 2 – Maintenance Importance and Intent

The importance of maintenance for the proper functioning of stormwater control facilities cannot be over-emphasized. A substantial portion of failures (clogging of filters, resuspension of sediments, loss of storage capacity, etc.) are due to inadequate maintenance. Stormwater BMP maintenance is essential to ensure that BMPs function as intended throughout their life cycle.

The fundamental goals of maintenance activities are to ensure the entire flow regime and treatment train designed for this site continue to fully function. For this site these include:

- Maintain designed stormwater infiltration capacity
- Maintain designed stormwater detention/retention volume
- Maintain ability of storm facility to attenuate flow rates
- Maintain ability to safely convey design stormwater flows
- Maintain ability to treat stormwater runoff quality
- Preserve soil and plant health, as well as stormwater flow contact with plant and soil systems
- Clearly identify systems so they can be protected
- Keep maintenance costs low
- Prevent large-scale or expensive stormwater system failures
- Prevent water quality violations or damage to downstream properties

The intent of this section and manual is to pass on to the responsible party(s) all the information critical to understand the design of the system, risks and considerations for proper use, suggestions for maintenance frequencies, and cost so that realistic budgets can be established.

3.0 Maintenance and Source Control Manual Section 3 – Responsible Parties

The property owner will be responsible for the maintenance of the BMPs on site.

4.0 Maintenance and Source Control Manual Section 4 – Facilities Requiring Maintenance

- Contech Water quality system
- StormTech Chambers model 3500
- Catch Basins
- Drain Pipes
- Trees
- Landscaping

5.0 Maintenance and Source Control Manual Section 5 – Maintenance Instructions

The parties responsible for maintenance must review and apply the maintenance requirements contained herein. These maintenance instructions outline conditions for determining if maintenance actions are required, as identified through inspection. However, they are not intended to be measures of the facility's required condition at all times between inspections. Exceedance of these conditions at any time between inspections or maintenance activity does not automatically constitute a violation of these standards. However, based upon inspection observations, the inspection and maintenance presented in the checklists shall be adjusted to minimize the length of time that a facility is in a condition that requires maintenance action. For facilities not owned and maintained by the county, a log of maintenance activity that indicates what actions were taken must be kept on site and be available for inspection by the county. See Attachment A – Maintenance Checklist.

6.0 Maintenance and Source Control Manual Section 6 – Vegetation Maintenance

The property owner will have a responsibility to maintain the vegetated flowpath for all proposed dispersion trenches if applicable. All flowpath areas shall be maintained per maintenance checklist provided and must consist of either undisturbed native landscape, or well-established lawn, landscape, groundcover over soils that meets the preservation and amendment BMP requirements.


7.0 Maintenance and Source Control Manual Section 7 – Pollution Source Control Measures

The plans provided with this report will be followed in the field to reduce the potential for pollution. It is anticipated that the only source of pollution generated on site will be from the minimal disturbance of soils which will be controlled by following the provided SWPPP and TESC plan.

8.0 Maintenance and Source Control Manual Section 8 – Annual Cost of Maintenance

Maintenance costs for stormwater management facilities shall be determined by the property owner.

Figure 1: Map of Project Area



Appendix A – Maintenance Checklists

#3 – Maintenance Checklist for Closed Detention Systems (Tanks/Vaults):

Drainage System Feature	Defect or Problem	Condition When Maintenance Is Needed	Results Expected When Maintenance Is Performed
Storage Area	Plugged Air Vents	One-half of the cross-section of a vent is blocked at any point or the vent is damaged.	Vents open and functioning. Remove blockage or replace air vent if damaged.
Storage Area	Debris and Sediment	Accumulated sediment depth exceeds 10 percent of the diameter of the storage area for one-half length of storage vault or any point depth exceeds 15 percent of diameter.	All sediment and debris removed from storage area.
Storage Area	Joints Between Tank/Pipe Section	Any openings or voids allowing material to be transported into facility. (Will require engineering analysis to determine structural stability.)	All joint between tank/pipe sections are sealed.
Storage Area	Tank Pipe Bent Out of Shape	Any part of tank/pipe is bent out of shape more than 10 percent of its design shape. (Review required by engineer to determine structural stability.)	Tank/pipe repaired or replaced to design.
Storage Area	Vault Structure Includes Cracks in Wall, Bottom, Damage to Frame and/or Top Slab	Cracks wider than one-half inch and any evidence of soil particles entering the structure through the cracks, or maintenance/inspection personnel determines that the vault is not structurally sound.	Vault replaced or repaired to design specifications and is structurally sound.
Storage Area	Vault Structure Includes Cracks in Wall, Bottom, Damage to Frame and/or Top Slab	Cracks wider than one-half inch at the joint of any inlet/outlet pipe or any evidence of soil particles entering the vault through the walls.	No cracks more than one-fourth inch wide at the joint of the inlet/outlet pipe. No water or soil entering vault through joints or walls.
Crest Gauge	Crest Gauge Missing/Broken	Crest gauge is not functioning properly, has been vandalized, or is missing.	Crest gauge present and functioning. <i>Repair/replace crest gauge if missing or broken.</i>
Manhole	Cover Not in Place	Cover is missing or only partially in place. Any open manhole requires maintenance.	Manhole access cover/ lid is in place and secure.
Manhole	Locking Mechanism Not Working	Mechanism cannot be opened by one maintenance person with proper tools. Bolts into frame have less than one-half inch of thread (may not apply to self-locking lids).	Mechanism opens with proper tools.
Manhole	Cover Difficult to Remove	One maintenance person cannot remove lid after applying normal lifting pressure. Intent is to keep cover from sealing off access to maintenance.	Cover can be removed and reinstalled by one maintenance person.
Manhole	Ladder Rungs Unsafe	Ladder is unsafe due to missing rungs, misalignment, not securely attached to structure wall, rust, or cracks.	Ladder meets design standards. Allows maintenance person safe access.

If you are unsure whether a problem exists, contact a professional engineer.

Tanks and vaults are a confined space. Visual inspections should be performed aboveground. If entry is required, it should be performed by qualified personnel.

#5 – Maintenance Checklist for Catch Basins:

Drainage System Feature	Defect or Problem	Condition When Maintenance Is Needed	Results Expected When Maintenance Is Performed
General	"Dump no pollutants" (or similar) stencil or stamp not visible	Stencil or stamp should be visible and easily read.	Warning signs (e.g., "Dump No Waste-Drains to Stream" or "Only rain down the drain"/ "Puget Sound starts here") painted or embossed on or adjacent to all storm drain inlets.
General	Trash and Debris	Trash or debris which is located immediately in front of the catch basin opening or is blocking inlet capacity by more than 10 percent.	No trash or debris located immediately in front of catch basin or on grate opening.
General	Trash and Debris	Trash or debris (in the basin) that exceeds 60 percent of the sump depth as measured from the bottom of basin to invert of the lowest pipe into or out of the basin, but in no case less than a minimum of 6 inches clearance from the debris surface to the invert of the lowest pipe.	No trash or debris in the catch basin.
General	Trash and Debris	Trash or debris in any inlet or outlet pipe blocking more than one-third of its height.	Inlet and outlet pipes free of trash or debris.
General	Trash and Debris	Dead animals or vegetation that could generate odors that could cause complaints or dangerous gases (e.g., methane).	No dead animals or vegetation present within the catch basin.
General	Sediment	Sediment (in the basin) that exceeds 60 percent of the sump depth as measured from the bottom of basin to invert of the lowest pipe into or out of the basin, but in no case less than a minimum of 6 inches clearance from the sediment surface to the invert of the lowest pipe.	No sediment in the catch basin.
General	Structure Damage to Frame and/or Top Slab	Top slab has holes larger than 2 square inches or cracks wider than one-fourth inch.	No holes and cracks in the top slab allowing material to run into the basin.
General	Structure Damage to Frame and/or Top Slab	Frame not sitting flush on top slab, i.e., separation of more than three-fourth inch of the frame from the top slab. Frame not securely attached.	Frame is sitting flush on the riser rings or top slab and firmly attached.
General	Fractures or Cracks in Basin Walls/ Bottom	Maintenance person judges that structure is unsound.	Basin replaced or repaired to design standards.
General	Fractures or Cracks in Basin Walls/ Bottom	Grout fillet has separated or cracked wider than one-half-inch and longer than 1 foot at the joint of any inlet/outlet pipe or any evidence of soil particles entering catch basin through cracks.	Pipe is regouted and secure at basin wall.
General	Settlement/ Misalignment	If failure of basin has created a safety, function, or design problem.	Basin replaced or repaired to design standards.
General	Vegetation	Vegetation growing across and blocking more than 10 percent of the basin opening.	No vegetation blocking opening to basin.

#5 – Maintenance Checklist for Catch Basins:

Drainage System Feature	Defect or Problem	Condition When Maintenance Is Needed	Results Expected When Maintenance Is Performed
General	Vegetation	Vegetation growing in inlet/outlet pipe joints that is more than 6 inches tall and less than 6 inches apart.	No vegetation or root growth present.
General	Contamination and Pollution	Any evidence of oil, gasoline, contaminants or other pollutants.	No contaminants or pollutants present. <i>(Coordinate removal/cleanup with Pierce County Surface Water Management 253-798-2725 and/or Dept. of Ecology Spill Response 800-424-8802.)</i>
Catch Basin Cover	Cover Not in Place	Cover is missing or only partially in place. Any open catch basin requires maintenance.	Catch basin cover is in place and secured.
Catch Basin Cover	Locking Mechanism Not Working	Mechanism cannot be opened by one maintenance person with proper tools. Bolts into frame have less than one-half-inch of thread.	Mechanism opens with proper tools.
Catch Basin Cover	Cover Difficult to Remove	One maintenance person cannot remove lid after applying normal lifting pressure. (Intent is keep cover from sealing off access to maintenance.)	Cover can be removed by one maintenance person.
Ladder	Ladder Rungs Unsafe	Ladder is unsafe due to missing rungs, not securely attached to basin wall, misalignment, rust, cracks, or sharp edges.	Ladder meets design standards and allows maintenance person safe access.
Grates	Grate Opening Unsafe	Grate with opening wider than seven-eighths of an inch.	Grate opening meets design standards.
Grates	Trash and Debris	Trash and debris that is blocking more than 20 percent of grate surface inletting capacity.	Grate free of trash and debris.
Grates	Damaged or Missing	Grate missing or broken member(s) of the grate.	Grate is in place and meets design standards.

If you are unsure whether a problem exists, contact a professional engineer.

#20 – Maintenance Checklist for Grounds (Landscaping):

Drainage System Feature	Defect or Problem	Condition When Maintenance Is Needed	Results Expected When Maintenance Is Performed
General	Weeds (nonpoisonous)	Weeds growing in more than 20 percent of the landscaped area (trees and shrubs only). Any evidence of noxious weeds as defined in the Pierce County Noxious Weeds List .	Weeds present in less than 5 percent of the landscaped area.
General	Insect Hazard	Any presence of poison ivy or other poisonous vegetation or insect nests.	No poisonous vegetation or insect nests present in landscaped area.
General	Trash or Litter	See Detention Ponds (Checklist #1).	See Detention Ponds (Checklist #1).
General	Erosion of Ground Surface	Noticeable rills are seen in landscaped areas.	Causes of erosion are identified and steps taken to slow down/spread out the water. Eroded areas are filled, contoured, and seeded.
Trees and shrubs	Damage	Limbs or parts of trees or shrubs that are split or broken which affect more than 25 percent of the total foliage of the tree or shrub.	Trim trees/shrubs to restore shape. Replace trees/shrubs with severe damage.
Trees and shrubs	Damage	Trees or shrubs that have been blown down or knocked over.	Tree replanted, inspected for injury to stem or roots. Replace if severely damaged.
Trees and shrubs	Damage	Trees or shrubs which are not adequately supported or are leaning over, causing exposure of the roots.	Stakes and rubber-coated ties placed around young trees/shrubs for support.

#29 – Maintenance Checklist for Bioretention (Cells, Swales, and Planter Boxes):

Drainage System Feature	Defect or Problem	Condition When Maintenance Is Needed	Results Expected When Maintenance Is Performed
General	Trash	Trash and debris present.	No trash and debris present.
Concrete Sidewalls	Cracks or Failure in Concrete Planter Reservoir	Cracks wider than 0.5 inch or maintenance/inspection personnel determine that the planter is not structurally sound.	Concrete repaired or replaced.
Rockery Sidewalls	Instable Rockery	Rock walls are insecure.	Rockery sidewalls are stable (may require consultation with professional engineer, particularly for walls 4 feet or greater in height).
Earthen Side Slopes and Berms	Failure in Earthen Reservoir (Embankments, Dikes, Berms, and Side Slopes)	Erosion (gullies/rills) greater than 2 inches around inlets, outlet, and along side slopes.	Source of erosion eliminated and damaged area stabilized (regrade, rock, vegetation, erosion control blanket). For deep channels or cuts (over 3 inches in ponding depth), temporary erosion control measures are in place until permanent repairs can be made.
Earthen Side Slopes and Berms	Failure in Earthen Reservoir (Embankments, Dikes, Berms, and Side Slopes)	Erosion of sides causes slope to become a hazard.	The hazard is eliminated and slopes are stabilized.
Earthen Side Slopes and Berms	Failure in Earthen Reservoir Embankments, Dikes, Berms, and Side Slopes)	Settlement greater than 3 inches (relative to undisturbed sections of berm).	The design height is restored with additional mulch.
Earthen Side Slopes and Berms	Failure in Earthen Reservoir (Embankments, Dikes, Berms, and Side Slopes)	Downstream face of berm or embankment wet, seeps or leaks evident.	Holes are plugged and berm is compacted. May require consultation with professional engineer, particularly for larger berms.
Earthen Side Slopes and Berms	Failure in Earthen Reservoir (Embankments, Dikes, Berms, and Side Slopes)	Any evidence of rodent holes or water piping around holes if facility acts as dam or berm.	Rodents (see "Pests: Insects/Rodents") removed or destroyed and berm repaired/ compacted.
Ponding Area	Sediment or Debris Accumulation	Accumulation of sediment or debris to extent that infiltration rate is reduced (see "Ponded water") or surface storage capacity significantly impacted.	Sediment cleaned out to restore facility shape and depth. Damaged vegetation is replaced and mulched. Source of sediment identified and controlled (if feasible).
Ponding Area	Leaf Accumulation	Accumulated leaves in facility.	No leaves clogging outlet structure or impeding water flow.
Ponding Area	Basin Inlet via Surface Flow	Soil is exposed or signs of erosion are visible.	Erosion sources repaired and controlled.
Curb Cut Inlet	Sediment or Debris Accumulation	Sediment, vegetation, or debris partially or fully blocking inlet structure.	Curb cut is clear of debris. Source of the blockage is identified and action is taken to prevent future blockages.

#29 – Maintenance Checklist for Bioretention (Cells, Swales, and Planter Boxes):

Drainage System Feature	Defect or Problem	Condition When Maintenance Is Needed	Results Expected When Maintenance Is Performed
Splash Block Inlet	Water Not Properly Directed to Facility	Water is not being directed properly to the facility and away from the inlet structure.	Blocks are reconfigured to direct water to facility and away from structure.
Splash Block Inlet	Erosion	Water disrupts soil media.	Splash block is reconfigure/repared.
Inlet/outlet pipe	Damaged Pipe	Pipe is damaged.	Pipe is repaired/replaced. No cracks more than 0.25 inches wide at the joint of inlet/outlet pipes exist.
Inlet/outlet pipe	Clogged Pipe	Pipe is clogged.	Pipe is clear of roots or debris. Source of the blockage is identified and action is taken to prevent future blockages.
Inlets/outlet and access pathways	Blocked Access	Maintain access for inspections.	Vegetation is cleared within 1 foot of inlets and outlets. Access pathways are maintained.
Ponding Area	Erosion	Water disrupts soil media.	No eroded or scoured areas in bioretention area. Cause of erosion or scour addressed. A cover of rock or cobbles or other erosion protection measure maintained (e.g., matting) to protect the ground where concentrated water enters or exits the facility (e.g., a pipe, curb cut or swale).
Trash Rack	Trash or Debris Accumulation	Trash or debris present on trash rack.	No trash or debris on trash rack. Clean and dispose trash.
Trash Rack	Damaged Trash Rack	Bar screen damaged or missing.	Barrier repaired or replaced to design standards.
Check Dams and Weirs	Sediment or Debris Accumulation	Sediment, vegetation, or debris accumulated at or blocking (or having the potential to block) check dam, weir, or orifice.	Blockage is cleared. Identify the source of the blockage and take actions to prevent future blockages.
Check Dams and Weirs	Erosion	Erosion and/or undercutting is present.	No eroded or undercut areas in bioretention area. Cause of erosion or undercutting addressed. Check dam or weir is repaired.
Check Dams and Weirs	Unlevel Top of Weir	Grade board or top of weir damaged or not level.	Weir restored to level position.
Flow Spreader	Sediment Accumulation	Sediment blocks 35 percent or more of ports/notches or, sediment fills 35 percent or more of sediment trap.	Sediment removed and disposed of.
Flow Spreader	Damaged or Unlevel Grade Board/Baffle	Grade board/baffle damaged or not level.	Board/baffle removed and reinstalled to level position.
Overflow/emergency spillway	Sediment or Debris Accumulation	Overflow spillway is partially or fully plugged with sediment or debris.	No sediment or debris in overflow.
Overflow/emergency spillway	Erosion	Native soil is exposed or other signs of erosion damage are present.	Erosion repaired and surface of spillway stabilized.

#29 – Maintenance Checklist for Bioretention (Cells, Swales, and Planter Boxes):

Drainage System Feature	Defect or Problem	Condition When Maintenance Is Needed	Results Expected When Maintenance Is Performed
Overflow/emergency spillway	Missing Spillway Armament	Spillway armament is missing.	Armament replaced.
Underdrain	Blocked Underdrain	Plant roots, sediment or debris reducing capacity of underdrain. Prolonged surface ponding (see "Bioretention Soil").	Underdrains and orifice are free of sediment and debris.
Bioretention soil	Ponded Water	Excessive ponding water: Water overflows during storms smaller than the design event or ponded water remains in the basin 48 hours or longer after the end of a storm.	Cause of ponded water is identified and addressed: 1. Leaf or debris buildup is removed 2. Underdrain is clear 3. Other water inputs (e.g., groundwater, illicit connections) investigated 4. Contributing area verified If steps #1-4 do not solve the problem, imported bioretention soil is replaced and replanted.
Bioretention soil	Protection of Soil	Maintenance requiring entrance into the facility footprint.	Maintenance is performed without compacting bioretention soil media.
Vegetation	Bottom Swale and Upland Slope Vegetation	Less than 75 percent of swale bottom is covered with healthy/ surviving vegetation.	Plants are healthy and pest free. Cause of poor vegetation growth addressed. Bioretention area is replanted as necessary to obtain 75 percent survival rate or greater. Plant selection is appropriate for site growing conditions.
Trees and shrubs	Causing Problems for Operation of Facility	Large trees and shrubs interfere with operation of the basin or access for maintenance.	Trees and shrubs do not hinder facility performance or maintenance activities. Prune or remove large trees and shrubs.
Trees and shrubs	Dead Trees and Shrubs	Standing dead vegetation is present.	Trees and shrubs do not hinder facility performance or maintenance activities. Dead vegetation is removed and cause of dead vegetation is addressed. Specific plants with high mortality rate are replaced with more appropriate species.
Trees and shrubs adjacent to vehicle travel areas (or areas where visibility needs to be maintained)	Safety Issues	Vegetation causes some visibility (line of sight) or driver safety issues.	Appropriate height for sight clearance is maintained. Regular pruning maintains visual sight lines for safety or clearance along a walk or drive. Tree or shrub is removed or transplanted if presenting a continual safety hazard.
Emergent Vegetation	Conveyance Blocked	Vegetation compromises conveyance.	Sedges and rushes are clear of dead foliage.
Mulch	Lack of Mulch	Bare spots (without much cover) are present or mulch covers less than 2 inches.	Facility has a maximum 3-inch layer of an appropriate type of mulch and mulch is kept away from woody stems.
Vegetation	Accumulation of Clippings	Grass or other vegetation clippings accumulate to 2 inches or greater in depth.	Clippings removed.

#29 – Maintenance Checklist for Bioretention (Cells, Swales, and Planter Boxes):

Drainage System Feature	Defect or Problem	Condition When Maintenance Is Needed	Results Expected When Maintenance Is Performed
Noxious Weeds	Presence of Noxious Weeds	Listed noxious vegetation is present. See Pierce County Noxious Weeds List .	Noxious and nuisance vegetation removed according to applicable regulations. No danger of noxious vegetation where County personnel or the public might normally be. It is strongly encouraged that herbicides and pesticides not be used in order to protect water quality.
Vegetation	Weeds	Weeds are present (unless on edge and providing erosion control).	Weed material removed and disposed of. It is strongly encouraged that herbicides and pesticides not be used in order to protect water quality.
Excessive Vegetation	Adjacent Facilities Compromised	Low-lying vegetation growing beyond facility edge onto sidewalks, paths, or street edge poses pedestrian safety hazard or may clog adjacent permeable pavement surfaces due to associated leaf litter, mulch, and soil.	Vegetation does not impede function of adjacent facilities or pose as safety hazard. Groundcovers and shrubs trimmed at facility edge. Excessive leaf litter is removed.
Excessive Vegetation	Causes Facility to Not Function Properly	Excessive vegetation density inhibits stormwater flow beyond design ponding or becomes a hazard for pedestrian and vehicular circulation and safety.	Pruning and/or thinning vegetation maintains proper plant density and aesthetics. Plants that are weak, broken, or not true to form are removed or replaced in-kind. Appropriate plants are present.
Irrigation (if any)	NA	Irrigation system present.	Manufacturer's instructions for O&M are met.
Plant watering	Plant Establishment	Plant establishment period (1-3 years).	Plants are watered as necessary during periods of no rain to ensure plant establishment.
Summer Watering (after establishment)	Drought Period	Longer term period (3+ years).	Plants are watered as necessary during drought conditions and trees are watered up to five years after planting.
Spill Prevention and Response	Spill Prevention	Storage or use of potential contaminants in the vicinity of facility.	Spill prevention measures are implemented whenever handling or storing potential contaminants.
Spill Prevention and Response	Spill Response	Any evidence of contaminants such as oil, gasoline, concrete slurries, paint, etc.	Spills are cleaned up as soon as possible to prevent contamination of stormwater. No contaminants or pollutants present. (Coordinate source control, removal, and/or cleanup with Pierce County Surface Water Management 253-798-2725 and/or Dept. of Ecology Spill Response 800-424-8802.)
Safety	Safety (Slopes)	Erosion of sides causes slope to exceed 1:3 or otherwise becomes a hazard.	Actions taken to eliminate the hazard.
Safety	Safety (Hydraulic Structures)	Hydraulic structures (pipes, culverts, vaults, etc.) become a hazard to children playing in and around the facility.	Actions taken to eliminate the hazard (such as covering and securing any openings).

#29 – Maintenance Checklist for Bioretention (Cells, Swales, and Planter Boxes):

Drainage System Feature	Defect or Problem	Condition When Maintenance Is Needed	Results Expected When Maintenance Is Performed
Aesthetics	Aesthetics	Damage/vandalism/debris accumulation.	Facility restored to original aesthetic conditions.
Aesthetics	Edging	Grass is starting to encroach on swale.	Edging repaired.
Pest Control	Pests: Insects/Rodents	Pest of concern is present and impacting facility function.	Pests removed or destroyed and facility returned to original functionality. Do not use pesticides or <i>Bacillus thuringiensis israelensis</i> (Bti).
Pest Control	Mosquitoes	Standing water remains in the basin for more than three days following storms.	All inlets, overflows and other openings are protected with mosquito screens. No mosquito infestation present.

If you are unsure whether a problem exists, contact a professional engineer.